

Trouble Shooting Guide for Container Candles

Pull-away of wax from container walls:

- Check container temperatures before pouring
- Check pour temperature
- Check cooling area for drafts resulting in non-uniform cooling

Excessive Shrinkage:

- Note that a small amount of shrinkage is normal, and that this will be more noticeable on large volume candles.
- Check pour temperature

Blistering and Pitting:

- Check jar temperature prior to pouring
- Check pour temperature
- Check for possible temperature fluctuations during storage and transportation